

The Undercoat-Only Pet Comb!™

Use Instructions

If fur is tangled or matted, start by using the CoatHook's detangler microhooks. Hold the CoatHook so the hollow side of the handle faces away from your pet. Lay the tines on the fur with the handle almost lying against your pet's body. Pull the CoatHook back toward the handle, increasing the steepness of the handle's angle as you go. Repeat until fur is untangled enough to be combed.



DESHEDDING

More Effective Angle

If fur is not tangled or matted, use the single microhooks at the tips of the tines to reach beneath the guard coat and remove loose undercoat. With the hollow side of the handle toward your pet, pull the CoatHook toward the end of the handle. For some coats, a shallower angle is typically more effective and a steeper angle is less effective. Experiment to find an angle that works best for your pet's fur.

LEARN MORE at TheCoatHook.com



Less Effective Angle

The CoatHook is not a toy; please don't allow your pet to play with or chew it. That could ruin the CoatHook and/or injure your pet.